

Preparing a dongle for operation

The current Guardant dongles support Windows and Linux platforms and also can operate without the initial installation of a special driver (HID-mode).

The preparation of a dongle for operation on various platforms varies. These differences will be explained in more detail later.